

TIP

If your machine jams, cut tape in the air with scissors, not a razor.



Preventative Maintenance

HOW TO MAINTAIN TAPE MACHINES

Follow the below procedure and tips to extend the life of your tape machine.

- Every Friday wipe down the machine with a warm damp rag. Go over outer part first, then wipe the part where the tape comes out.
- Remove brushes and wash in warm water. You can use soapy water if they are heavily soiled. Rinse well and wrap in moist paper towel.
- Clean the black tray with warm soapy water. If you see buildup, you can use Nassco® Pro Series 73 Delimer (Item# N-02020) or Nassco® Pro Series 01 Low Acid Bowl Cleaner (Item# N-02002). Rinse well and leave out over the weekend.
- Remove the frosty water jug and empty it. Rinse with warm soapy water. If you see buildup you can use Pro Series 73 Delimer or Pro Series 01 Low Acid Bowl Cleaner again. Rinse well and let dry with cap OFF.
- No additive should be put in the water when you are using the tape machine.
- If your tape machine jams, do not cut the tape with a scissors or razor blade against the machine. Hold the tape out and then make your cut in the air so you don't gouge your machine.