

# 4 WHEELERS

## Tools Needed

- Food Surface Scrub Brush
- Non-Abrasive Scouring Pad
- Properly Equipped 3-Lever Dilution Center
- Quat Test Strips (QT-40 or equivalent)
- Chemical Resistant Gloves

## Products Needed

Spic and Span®  
Liquid Floor and Multi-  
Surface Cleaner




Clean Quick® Broad  
Range Quaternary  
Sanitizer




**FREQUENCY OF CLEANING:** Weekly

**SPECIAL DIRECTIONS FOR THIS TASK:** Clean all 4 Wheelers in the department at one time. If sensitivity to cleaning solutions is a concern, wear disposable gloves.




### STEP 1

- Scrape off any heavy buildup off of the 4 wheeler.




### STEP 2

- Turn on the wash side of the 3-lever and make sure all other levers are in the off position.




### STEP 3

- Wet down all inside surfaces of the 4 wheeler with cleaning solution, using the hose from the 3-lever Dilution Center.




### STEP 4

- Scrub all surfaces of the 4 wheeler with a non abrasive scouring pad.
- Make sure that all surfaces are cleaned, including corners and areas around wheel mountings.




### STEP 5

- Turn off the wash solution on the 3-lever Dilution Center.
- Turn on the rinse solution on the 3-lever Dilution Center.




**NOTE:** After using the cleaning solution the hose still holds about 1 gallon of the cleaning solution. Clean rinse water will begin to flow once the cleaning solution that was left in the hose has run through the hose.




### STEP 6

- Rinse all surfaces of the 4 wheelers using the hose from the 3-lever.




### STEP 7

- Turn off the rinse solution on the 3-lever Dilution Center.
- Turn on the sanitize solution on the 3-lever Dilution Center.



**NOTE:** After using the rinse water the hose still holds about 1 gallon of this water. Sanitizer will begin to flow once the rinse water that was left in the hose has run through the hose. Allow at least 15 seconds for this to occur to ensure Sanitizer is being applied to the surfaces.



### STEP 8

- Sanitize all surfaces of the 4 wheelers using the hose from the 3-lever Dilution Center.
- Allow to air dry



### STEP 9

- If used, remove and discard disposable gloves.
- Wash hands before returning to service area.

**NOTE:** Always use test strips before expiration date printed on case.